

Statler User Guide

KEYPAD SWITCHES BY ENTRY DOOR



Suite On

- Turns on the lights on (Ceiling lights in living area and standing lamp)
- Opens Sheers and Drapes

Suite Off

- Turns on the lights off (Ceiling lights in living area and standing lamp)
- Resets the bathroom occupancy sensor to turn the lights on when occupancy is detected.
- Turns off Television
- Closes the Sheers

Drapes

- Toggles the drapes open and closed.
- It takes approximately 15 seconds for the drape to open or close.
- A second button press during the 15 seconds (while drape is in motion) will stop the drape at that position.

Sheers

- Toggles the sheers open and closed.
- It takes approximately 15 seconds for the sheer to open or close.
- A second button press during the 15 seconds (while sheer is in motion) will stop the sheer at that position.

Lamp

- Toggles the standing lamp on and off.
- Note if the lamp does not turn completely off at night, please alert the hotel staff to change your light bulb.

PRIVACY (DO NOT DISTURB) AND MAKE UP ROOM DOOR SIGN AND DOORBELL



Privacy

- Pressing this button will turn the doorbell button on the sign outside your room to red and turns off the doorbell so it will not ring and you will not be disturbed.

Make Up Room

- Pressing this button will turn the doorbell button on the sign outside your room to green so that the staff is notified to clean your room.

BATHROOM LIGHTS



Ceiling Lights

- Pressing this button will turn lights in your bathroom ceiling on or off. Green light indicates the lights are on and the White lights are to assist in finding the light switches in the dark.

Vanity Lights

- Pressing this button will turn lights in your bathroom ceiling on or off. Green light indicates the lights are on and the White lights are to assist in finding the light switches in the dark.

Occupancy Sensor

- Your bathroom has an automatic occupancy sensor that will automatically turn on the bathroom Ceiling lights to 60% of full brightness upon entry to the bathroom.
- Lights will stay on for 25 minutes after no occupancy (to accommodate for showers, etc.)
- If either light switch (Vanity or Ceiling) is manually pressed, the occupancy sensor is disabled. When light switch is again manually pressed off, the occupancy sensor is reset to automatically turn on lights when next motion is detected.

KEYPAD AT THE BEDSIDE



Sconces

- Turns the wall sconce lights at the headboard of your bed on or off on. This controls both wall sconces. For individual bedside lights, please use the fold out light in your bed's headboard. These lights have a manual switch to turn on or off.

Drapes

- Toggles the drapes open and closed. The first button press will open the drapes. A second button press will close the drapes.
- It takes approximately 15 seconds for the sheer to open or close.
- A second button press during the 15 seconds (while sheer is in motion) will stop the sheer at that position.

Sheers


- Toggles the sheers open and closed. The first button press will open the sheers. A second button press will close the sheers.
- It takes approximately 15 seconds for the sheer to open or close.
- A second button press during the 15 seconds (while sheer is in motion) will stop the sheer at that position.

Suite Off

- Turns on the lights off (Ceiling lights in living area and standing lamp)
- Pressing this button will turn the doorbell button on the sign outside your room to red and turns off the doorbell so it will not ring and you will not be disturbed.


TOUCH PANEL AT THE BEDSIDE






Watch Icon

- Turns on your TV and takes you to the touch panels TV control, shown below. This allows you to change channels, control volume and access the normal DirecTV functions of your DirecTV system in your room.



Lighting Icon

- Allows you to change your lighting and dim the lights by simply sliding your finger to the desired lighting level.
- Provides access to the Suite On and Suite Off functions just like the buttons at the Entry Door keypad.




Services Icon

- Another way to set your Do Not Disturb (Privacy) setting on your room, just like the Privacy Button on your Entry Door keypad.



Comfort Icon

- Allows you to customize your temperature settings for your thermostat in a "Nest™" style layout.



Wake/Sleep Icon

- The Wakeup icon allows you to set your morning wakeup alarm with customized room settings. Settings include:
 - Opening the drapes
 - Raising or lowering the temperature
 - Customizing the lighting
- The Goodnight icon allows you to set a timer that will customize the setting while you sleep. Settings include:
 - Turning off your TV
 - Closing the drapes
 - Raising or lowering the temperature
 - Customizing the lighting

REMOTE CONTROLS



Control4 (Black Remote)—Living Area TV Only

- The Red Home Screen button will turn on your TV and allow you to use this remote control to access the same icons and functions that are available on the touch panel.
- To move around the TV's On Screen Navigator, use the arrows on the remote.
- The Room Off button will turn off the TV.



DirecTV (White Remote)- Suites only with Additional TV in Sitting Room

- This is a standard DirecTV remote.